

Installation Instructions DSC v120

18.10.2021

1. copy the file „DBBC3 Control DSC_v120.exe“ in the folder C:\DBBC\bin
2. copy the firmware-file
 - dbbc3_DSC_1hv1_131021.bit (for DBBC3-1hv1)
 - dbbc3_DSC_2hv2_131021.bit (for DBBC3-2hv2)into the folder C:\DBBC_CONF\FilesDBBC
3. copy the config files
 - dbbc3_config_file_dsc_120.txt
 - dsc_core3H_1.fila10g, dsc_core3H_2.fila10g, ...into the folder C:\DBBC_CONF\DSC_120 (new subfolder!)
 - make sure there is a fila10g-file present for each Core3H in the system.
 - Use the example files as reference to modify your existing files from previous versions, there have been some changes in the config files from version v120.
4. follow the instructions in the manual
 - „Setting up the DBBC3 for DSC mode_v120.pdf“